

GENERAL CONTROLS

.A001\$




DEFAULT
SETTINGS

.P023\$



RESET

.A007\$



FIRMWARE
VERSION

BEEPER

.F012\$



BEEP OFF