

IntelliScanner

Step 1: Print this document. You cannot scan barcodes on-screen.

Step 2: Scan this barcode to enter "configuration mode":

Step 3: Choose options below to configure your scanner.



Keyboard layout:



U.S. (default)



UK



Italy



Portugal



France



Belgium



Japan



Hungary



Sweden



Denmark



Greece



Swiss



Germany



Netherlands



Finland



Slovakia



Norway



Spain



Yugoslavia



Yugoslavia Cyrillic

Step 3: Scan this barcode to finish configuration:

